

ACTION PLAN: "CLEANING & HYGIENE"

HYGIENE TRAVELS SAFE.

This procedure follows the routine approach to the vehicle: equipped with a disposable coverall, gloves and a mask, the washing machine will obtain a complete and correct hygiene of any vehicle (including means of public transport), respecting each of the following steps.



ALLEGRI
LIGHT-BLUE
MICROFIBER CLOTH



FOR-OXY READY



FIVE SUPER
SANITIZZANTE
as an alternative to
For-Oxy Ready, to be
diluted in 2,5% solution
with nebulized
system or with
electrostatic nebulizers.



DIK VETRI



PURE AIR SPRAY



DEO SANY



NEBULIZER



JAMINAL PLUS



MEDIUM BRISTLE
BRUSH



EASY CLEAN GUN



ELECTROSTATIC
NEBULIZER



01 • KEYS

For-Oxy Ready and disposable absorbent paper. Leave the key dry.



02 • VEHICLES EXTERNAL SURFACES

Spray Jaminal Plus on all external surfaces at a dilution solution of 5%, then rinse thoroughly with water. Avoid the product dry on the surfaces.



03 • HANDLE AND SUPPORTS

For-Oxy Ready and microfiber cloth. Bring the mats outside.



04 • GASKETS, SCREEN AND DOORS

For-Oxy Ready and microfiber cloth, suitable for rubber or plastic surfaces and on any chromium plating in aluminum or fabric.



05 • GLASSES

For-Oxy Ready and disposable absorbent paper, the product will tend to evaporate.



06 • OBJECTS AT HAND

The seat belts, the plastic parts of the seats, the steering wheel, the diverter, the handbrake, the sun visor, the rear view mirror, the touch-screen and the buttons. For-Oxy Ready and microfiber cloth.



07 • DASHBOARD

For-Oxy Ready and microfiber cloth. Spray directly on the rubber/plastic/leather/faux leather surface, then go over the dashboard. Carry out a test in a hidden place to check the compatibility of the materials.



08 • AIR VENTS

Spray For-Oxy Ready on the medium bristles of a brush and pass it inside the nozzle.

Do not dispense For-Oxy Ready directly into the vents to avoid the dripping of the product inside the air conditioning system and/or the risk of stains, if the material of the vents was recycled plastic.



09 • MATS, CARPETS AND FABRIC SEATS

For-Oxy Ready. Clean and leave the mats outside.



10 • SKY

Dispense Deo Sany abundantly over the entire surface.



11 • PEDALS

For-Oxy Ready and microfiber cloth.



12 • TRUNK

For-Oxy Ready and microfibre cloth, for both plastic and fabric parts.



13 • AIR CONDITIONING SYSTEM

Pure Air.

If necessary, remove the air conditioning filter and wash it under running water, then blow.

Then spray For-Oxy Ready, wait for the filter to dry and finally refit it.



14 • FLOOR MATS

Once treated with For-Oxy Ready, reposition them inside the vehicle.

The procedures involving the use of For-Oxy Ready can also be performed with the easy clean gun.